AWS

Day2 Lab3

Nada Mohamed Ahmed Hassan Eleshmawy

Mansoura Open Source

Date: 31/5/2025

LAB 3:

Create a new RDS instance of MySql engine then connect to it and create DB or Table with your name.

Step 1: Search for "RDS"

Step 1: Click "Create Database"

- 1. Choose Standard create.
- 2. Engine options:

Engine type: Choose MySQLVersion: Choose default (8.0.41)

version. Choose delauit (6.0.41)

Enable RDS Extended Support : checked

o Templates : free tier

Step 2: Settings


- 1. DB instance identifier:
 - → nadamohamed-ahmed-mysql-db
- 2. Master username:
 - → admin (default)
- 3. Password:
 - → Set a secure password : nadamohamedahmedmysqldbsecure123
 - $\rightarrow \text{Confirm password}$

Step 3: DB Instance Class (Free Tier)


- Choose:
 - o **db.t4g.micro** (default: Free Tier)
 - o Storage: 20 GB (default)

Step 4: Connectivity


- 1. VPC: Default VPC
- 2. Public access:
 - → Choose "Yes" (so we can connect to it from our device)
- 3. VPC security group (important):
 - → Choose "Choose Existing security group"
 - ightarrow Go to EC2 ightarrow security group ightarrow the "Default" ightarrow go to Inbound rules ightarrow click Edit
 - → Add a new rule for MySQL/Aurora




4. Click "Create Database"



Available now:






Part 2: Connect to our MySQL RDS

Step 1: Get Endpoint

- 1. After the instance is available, click on it.
- 2. Copy the **endpoint**:

nadamohamed-ahmed-mysql-db.c7ymw80c4cvr.eu-north-1.rds. amazonaws.com




Step 2: Allow our IP to Connect (We make this above but we should double check because this is very important)

- 1. Go to EC2 > Security Groups
- 2. Find the group assigned to RDS (the default).
- 3. Click Edit Inbound Rules
- 4. Add a rule:

Type: MySQL/Aurora

Port Range: 3306

Source: My IP



Step 3: Connect Using a MySQL Client

Using our terminal or command prompt

- 1. Open the terminal or command prompt
- 2. Run the MySQL client command to connect to our RDS instance:

mysql -h nadamohamed-ahmed-mysql-db.c7ymw80c4cvr.eu-north-1.rds.amazonaws.com -P 3306 -u admin -p

3. Enter your password


Password: nadamohamedahmedmysqldbsecure123

Part 3: Create a Database and Table

Step 1: Create a Database

CREATE DATABASE nada_mohamed_ahmed;

USE nada_mohamed_ahmed;



Step 2: Create a Table

```
CREATE TABLE nada_mohamed_ahmed_info(

id INT AUTO_INCREMENT PRIMARY KEY,
```

```
created_at TIMESTAMP DEFAULT CURRENT_TIMESTAMP
);

mysql> CREATE TABLE nada_mohamed_ahmed_info (
   -> id INT AUTO_INCREMENT PRIMARY KEY,
   -> full_name VARCHAR(100),
   -> created_at TIMESTAMP DEFAULT CURRENT_TIMESTAMP
   -> );
```

Step 3: Insert Data

full_name VARCHAR(100),

INSERT INTO nada_mohamed_ahmed_info (full_name) VALUES ('Nada Mohamed Ahmed Hassan Eleshmawy');

mysql> INSERT INTO nada_mohamed_ahmed_info (full_name) VALUES ('Nada Mohamed Ahmed Hassan Eleshmawy'); Query OK, 1 row affected (0.10 sec)

Step 4: View Table

SELECT * FROM nada_mohamed_ahmed_info;

Query OK, 0 rows affected (0.13 sec)